

NCJXT00054A00-D

WIRING DIAGRAM

- 1、AH: Auxiliary Electrical Heater
- HWTBH: Hot Water Tank Back-up Heater
- 2、PUMP P0: Circulation pump inside Hydrobox
- PUMP P1: Heating/Cooling Circuit 1 Circulation Pump
- PUMP P2: Heating/Cooling Circuit 2 Circulation Pump
- PUMP P3: Sanitary Hot Water System Circulation Pump
- 3、MV1&MV2
- MV1: Mixing valve for Heating/cooling circuit 1,24V DC power, 0~10V signal.
- MV2: Mixing valve for Heating/cooling circuit 2,24V DC power, 0~10V signal.
- 4、Communication Terminal for AB wire on back of WinCE controller.
- 4.3" WinCE: A to NO.8; B to NO.7

